


Bedienungsanleitung

Thermoelement
0600 1301-10

B+B Thermo-Technik GmbH
Heinrich-Hertz-Straße 4, D-78166 Donaueschingen
Tel. +49 771 83160, Fax +49 771 831650
info@bubthermo.de, www.bubthermo.de



1. Thermoelement NiCr-Ni, Typ K, mit Miniaturstecker (gelb oder grün) am Messgerät in die dafür vorgesehene Buchse einstecken.
2. Messwert am eingeschalteten Messgerät ablesen.
3. Messbereich des Mantelthermoelements -50°C bis $+260^{\circ}\text{C}$

The logo consists of the letters 'B+B' in a white serif font, centered within a red square.

Operating Instruction

Thermocouple
0600 1301-10

B+B Thermo-Technik GmbH

Heinrich-Hertz-Straße 4, D-78166 Donaueschingen
Phone +49 771 83160, Fax +49 771 831650
info@bubthermo.de, www.bubthermo.com

The logo consists of the letters 'B+B' in a white serif font, centered within a red square.

1. Plug in the Thermocouple NiCr-Ni, Type K with Miniature Plug (yellow or green) into the destined socket at the measurement device.
2. Read out the measured value of the measurement device.
3. Measuring range of Mineral Insulated Thermocouple $-50^{\circ}\text{C}\dots+260^{\circ}\text{C}$
($-58^{\circ}\text{F}\dots+500^{\circ}\text{F}$)

www.bubthermo.com