



PicoScope 2000 Series PC Oscilloscopes

Programmer's Guide

Contents

1 Introduction	1
1 Overview	1
2 Licence conditions	1
3 Trademarks	2
4 Warranty	2
5 Company details	2
2 Installation	3
1 Minimum system requirements	3
2 Installation instructions	3
3 Technical information	4
1 Driver	4
2 Programming overview	4
3 Device features	4
1 AC/DC coupling	4
2 Voltage ranges	4
3 Oversampling	5
4 Scaling	5
5 Signal generator	5
6 Triggering	5
7 Combining oscilloscopes	6
8 Sampling modes	6
4 Programming examples	11
1 C	11
2 Visual Basic	12
3 Delphi	12
4 Excel	12
5 Agilent VEE	12
6 LabVIEW	12
5 Functions	13
1 Introduction	13
2 ps2000_close_unit	14
3 ps2000_flash_led	15
4 ps2000_get_streaming_last_values	16
5 ps2000_get_streaming_values	17
6 ps2000_get_streaming_values_no_aggregation	19
7 ps2000_get_timebase	21
8 ps2000_get_times_and_values	22
9 ps2000_get_unit_info	24
10 ps2000_get_values	25
11 ps2000_last_button_press	26
12 ps2000_open_unit	27
13 ps2000_open_unit_async	28
14 ps2000_open_unit_progress	29
15 ps2000_overview_buffer_status	30
16 ps2000_ready	31
17 ps2000_run_block	32
18 ps2000_run_streaming	33

19	ps2000_run_streaming_ns	34
20	ps2000SetAdvTriggerChannelConditions	35
21	ps2000SetAdvTriggerChannelDirections	37
22	ps2000SetAdvTriggerChannelProperties	38
23	ps2000SetAdvTriggerDelay	40
24	ps2000_set_channel	41
25	ps2000_set_ets	42
26	ps2000_set_light	43
27	ps2000_set_led	44
28	ps2000SetPulseWidthQualifier	45
29	ps2000SetSigGenArbitrary	47
30	ps2000SetSigGenBuiltIn	49
31	ps2000_set_trigger	51
32	ps2000_set_trigger2	52
33	ps2000_stop	53
34	my_get_overview_buffers	54
6	Driver error codes	56
4	Glossary	57
	Index.....	59

1 Introduction

1.1 Overview

The PicoScope 2000 series PC Oscilloscopes are low-cost , high-performance instruments that are fully USB 2.0-capable and also backwards-compatible with USB 1.1. There is no need for an additional power supply, as power is taken from the USB port.

This manual is for programmers intending to write their own software using the PicoScope 2000 series API (Application Programming Interface). The scopes are also supplied with ready-to-use programs called PicoScope and PicoLog, which include their own on-line User's Guides.

Please read the important information in this introductory section and then proceed to the [Installation instructions](#)^[3].

1.2 Licence conditions

The material contained in this release is licensed, not sold. Pico Technology Limited grants a licence to the person who installs this software, subject to the conditions listed below.

Access

The licensee agrees to allow access to this software only to persons who have been informed of these conditions and agree to abide by them.

Usage

The software in this release is for use only with Pico products or with data collected using Pico products.

Copyright

Pico Technology claims the copyright of, and retains the rights to, all material (software, documents etc.) contained in this release. You may copy and distribute the entire release in its original state, but must not copy individual items within the release other than for backup purposes.

Liability

Pico Technology and its agents shall not be liable for any loss, damage or injury, howsoever caused, related to the use of Pico Technology equipment or software, unless excluded by statute.

Fitness for purpose

Because no two applications are the same, Pico Technology cannot guarantee that its equipment or software is suitable for a given application. It is your responsibility, therefore, to ensure that the product is suitable for your application.

Mission-critical applications

This software is intended for use on a computer that may be running other software products. For this reason, one of the conditions of the licence is that it excludes usage in mission-critical applications; for example, life-support systems.

1.3 Trademarks

Pico Technology Limited, PicoLog and PicoScope are internationally registered trademarks.

- Delphi is a registered trademark of Borland Software Corporation.
- LabView is a registered trademark of National Instruments Corporation.
- Pentium is a registered trademark of Intel Corporation.
- VEE is a registered trademark of Agilent Technologies.
- Windows, Excel and Visual Basic are registered trademarks of Microsoft Corporation.

1.4 Warranty

Pico Technology warrants upon delivery, and for a period of 24 months unless otherwise stated from the date of delivery, that the Goods will be free from defects in material and workmanship.

Pico Technology shall not be liable for a breach of the warranty if the defect has been caused by fair wear and tear, wilful damage, negligence, abnormal working conditions or failure to follow Pico Technology's spoken or written advice on the storage, installation, commissioning, use or maintenance of the Goods or (if no advice has been given) good trade practice; or if the Customer alters or repairs such Goods without the written consent of Pico Technology.

1.5 Company details

Address:

Pico Technology
James House
Colmworth Business Park
Eaton Socon
ST. NEOTS
Cambridgeshire
PE19 8YP
United Kingdom

Phone: +44 (0) 1480 396 395

Fax: +44 (0) 1480 396 296

Email:

Technical Support: support@picotech.com

Sales: sales@picotech.com

Web site: www.picotech.com

2 Installation

2.1 Minimum system requirements

For the PicoScope 2000 series PC Oscilloscope to operate correctly, a computer with the minimum system requirements to run Windows or the following (whichever is the higher specification) is required:

Item	Absolute minimum	Recommended minimum	Recommended full specification
Operating system	Windows XP SP2 or Vista (32-bit versions only)		
Processor	As required by Windows	300 MHz	1 GHz
Memory		256 MB	512 MB
Free disk space (Note 1)		1 GB	2 GB
Ports	USB 1.1 compliant port	USB 2.0 compliant port	

Note 1: The PicoScope software does not use all the disk space specified in the table. The free space is required to make Windows run efficiently.

2.2 Installation instructions

Important

Do not connect the PC Oscilloscope to your PC until you have installed the software.

- Install the software by following the steps in the printed *Installation Guide* supplied with your oscilloscope. You must install the PicoScope 6 PC Oscilloscope software even if you do not intend to use it, as it includes the driver and API DLL that you will need to write your own software.
- Connect the oscilloscope's USB port to the PC using the USB cable supplied. There is no need for an additional power supply, as the oscilloscope obtains its power from the PC.

Checking the installation

Once you have installed the software, ensure that the oscilloscope is connected to the PC and then start the PicoScope software. PicoScope should show a small 50 Hz or 60 Hz mains signal in the oscilloscope window when you touch the probe tip with your finger.

3 Technical information

3.1 Driver

Important

You must install the PicoScope software, which includes the driver for the PicoScope 2000 Series PC Oscilloscope, before plugging the oscilloscope into your computer for the first time.

(If you do plug in an oscilloscope before installing the driver, Windows will designate the device as *Unknown*. You will then need to manually delete the device using the Device Manager before you can install the correct driver.)

The Windows XP/Vista 32-bit driver, `picopp.sys`, is installed under the control of an information file, `picopp.inf`.

Once you have installed the PicoScope software, Windows will automatically install the driver when you plug in the oscilloscope for the first time.

3.2 Programming overview

The `ps2000.dll` library in your PicoScope installation directory allows you to program a PicoScope 2000 Series oscilloscope using standard C [function calls](#).^[13]

A typical program for capturing data consists of the following steps:

- [Open](#)^[27] the oscilloscope.
- Set up the input channels with the required [voltage ranges](#)^[4] and [coupling mode](#)^[4].
- Set up [triggering](#)^[5].
- Start capturing data. (See [Sampling modes](#)^[6], where programming is discussed in more detail.)
- Wait until the oscilloscope is ready.
- Copy data to a buffer.
- Stop capturing data.
- Close the oscilloscope.

Numerous [sample programs](#)^[11] are installed with your PicoScope software, if you select this option during installation. These show how to use the functions of the driver software in each of the modes available.

3.3 Device features

3.3.1 AC/DC coupling

Using the [ps2000_set_channel\(\)](#)^[41] function, each channel can be set to either AC or DC coupling. When AC coupling is used, any component of the signal below about 1 Hz is filtered out.

3.3.2 Voltage ranges

It is possible to set the gain for each channel with the [ps2000_set_channel\(\)](#)^[41] function. The input voltage ranges available depend on which type of oscilloscope is connected.

3.3.3 Oversampling

When the oscilloscope is operating at sampling rates less than the maximum, it is possible to oversample. Oversampling is taking more than one measurement during a time interval and returning an average. If the signal contains a small amount of noise, this technique can increase the effective [vertical resolution](#)^[58] of the oscilloscope by the amount given by the equation below:

$$\text{Increase in resolution (bits)} = (\log \text{ oversample}) / (\log 4)$$

Applicability	Available in block mode ^[7] only.
----------------------	--

3.3.4 Scaling

The driver normalises all readings to 16 bits, regardless of the [vertical resolution](#)^[58] of the oscilloscope. The following table shows the relationship between the reading from the driver and the signal level.

Constant	Reading	Voltage
PS2000_LOST_DATA	-32 768	Indicates a buffer overrun in fast streaming ^[10] mode.
PS2000_MIN_VALUE	-32 767	Negative full scale
0	0	Zero volts
PS2000_MAX_VALUE	32 767	Positive full scale

3.3.5 Signal generator

The PicoScope 2203, 2204 and 2205 PC Oscilloscopes have a built-in signal generator which is set up using [ps2000SetSigGenBuiltIn\(\)](#)^[49].

Applicability	PicoScope 2203, 2204 and 2205 oscilloscopes only.
----------------------	---

3.3.6 Triggering

PicoScope 2000 Series PC Oscilloscopes can either start collecting data immediately, or be programmed to wait for a trigger event to occur. In both cases you need to use the [ps2000_set_trigger\(\)](#)^[51] function or (for scopes that support advanced triggering) the [ps2000SetAdvTriggerChannelConditions\(\)](#)^[35] function. A trigger event can occur on any of the conditions available in the simple and advanced triggering modes.

Applicability	Available in block mode ^[7] and fast streaming mode ^[10] only. Calls to the ps2000_set_trigger() ^[51] and ps2000SetAdvTriggerChannelConditions() ^[35] functions have no effect in compatible streaming mode ^[9] .
----------------------	--

3.3.7 Combining oscilloscopes

It is possible to collect data using up to four PicoScope 2000 Series PC Oscilloscopes at the same time. Each oscilloscope must be connected to a separate USB port. If a USB hub is used it must be a powered hub.

To begin, call [ps2000_open_unit\(\)](#)^[27] to obtain a handle for each oscilloscope. All the other functions require this handle for oscilloscope identification. For example, to collect data from two oscilloscopes at the same time:

```
handle1 = ps2000_open_unit()
handle2 = ps2000_open_unit()

ps2000_set_channel(handle1)
... set up unit 1
ps2000_run_block(handle1)

ps2000_set_channel(handle2)
... set up unit 2
ps2000_run_block(handle2)

ready = FALSE
while not ready
    ready = ps2000_ready(handle1)
    ready &= ps2000_ready(handle2)

ps2000_get_values(handle1)
ps2000_get_values(handle2)
```

Note: it is not possible to synchronise the collection of data between oscilloscopes that are being used in combination.

3.3.8 Sampling modes

3.3.8.1 Introduction

PicoScope 2000 Series PC Oscilloscopes can run in various sampling modes.

- [Block mode](#).^[7] At the highest sampling rates, the oscilloscope collects data much faster than a PC can read it. In this case, the oscilloscope stores a block of data in an internal memory buffer, delaying transfer to the PC until the required number of data points have been sampled.
- [Streaming modes](#).^[9] At all but the highest sampling rates, these modes allow accurately timed data to be transferred back to the PC without gaps. The computer instructs the oscilloscope to start collecting data. The oscilloscope then transfers data back to the PC without storing it in its own memory, so the size of the data set is limited only by the size of the PC's memory. Sampling intervals from less than one microsecond to 60 seconds are possible. There are two streaming modes:
 - [Compatible streaming mode](#)^[9]
 - [Fast streaming mode](#)^[10]

3.3.8.2 Block mode

In block mode, the computer prompts the oscilloscope to collect a block of data in its internal memory. When the oscilloscope has collected the whole block, it signals that it is ready and then transfers the whole block to the computer's memory through the USB port.

The maximum number of values depends upon the size of the oscilloscope's memory. A PicoScope 2000 Series oscilloscope can sample at a number of different rates that correspond to the maximum sampling rate divided by 1, 2, 4, 8 and so on.

There is a separate memory buffer for each channel. When a channel is unused, its memory can be borrowed by the enabled channels. This feature is handled transparently by the driver.

The driver normally performs a number of setup operations before collecting each block of data. This can take up to 50 milliseconds. If it is necessary to collect data with the minimum time interval between blocks, avoid calling setup functions between calls to [ps2000_run_block\(\)](#)^[32], [ps2000_ready\(\)](#)^[31], [ps2000_stop\(\)](#)^[53] and [ps2000_get_values\(\)](#)^[25].

See [Using block mode](#)^[7] for programming details.

3.3.8.3 Using block mode

This is the general procedure for reading and displaying data in [block mode](#):^[7]

1. Open the oscilloscope using [ps2000_open_unit\(\)](#).^[27]
2. Select channel ranges and AC/DC coupling using [ps2000_set_channel\(\)](#).^[41]
3. Using [ps2000_set_trigger\(\)](#)^[51], set the trigger if required.
4. Using [ps2000_get_timebase\(\)](#)^[21], select timebases until you locate the required time interval per sample.
5. Start the oscilloscope running using [ps2000_run_block\(\)](#).^[32]
6. Wait until the oscilloscope says it is ready using [ps2000_ready\(\)](#).^[31]
7. Transfer the block of data from the oscilloscope using [ps2000_get_values\(\)](#)^[25] or [ps2000_get_times_and_values\(\)](#).^[22]
8. Display the data.
9. Repeat steps 5 to 8.
10. Stop the oscilloscope using [ps2000_stop\(\)](#).^[53]

3.3.8.4 ETS (Equivalent Time Sampling)

ETS is a way of increasing the effective sampling rate when working with repetitive signals. It is controlled by the [ps2000_set_trigger\(\)](#)^[51] and [ps2000_set_ets\(\)](#)^[42] functions.

ETS works by capturing many instances of a repetitive waveform, then combining them to produce a composite waveform that has a higher effective sampling rate than the individual instances. The maximum effective sampling rates that can be achieved with this method are listed in the Specifications table for your oscilloscope.

Because of the high sensitivity of ETS mode to small time differences, you must set up the trigger to provide a stable waveform that varies as little as possible from one capture to the next.

Applicability	<p>Block mode^[7] only.</p> <p>PicoScope 2104, 2105, 2203, 2204 and 2205 oscilloscopes.</p> <p>As ETS returns random time intervals, the ps2000_get_times_and_values()^[22] function must be used. The ps2000_get_values()^[25] function will return FALSE (0).</p> <p>Stable, repetitive signals only.</p>
---------------	---

3.3.8.5 Using ETS mode

This is the general procedure for reading and displaying data in [ETS](#)^[8] mode:

1. Open the oscilloscope using [ps2000_open_unit\(\)](#)^[27]
2. Select channel ranges and AC/DC switches using [ps2000_set_channel\(\)](#)^[41]
3. Using [ps2000_set_trigger\(\)](#)^[51], set the trigger if required.
4. Set ETS mode using [ps2000_set_ets\(\)](#)^[42]
5. Start the oscilloscope running using [ps2000_run_block\(\)](#)^[32]
6. Wait until the oscilloscope says it is ready using [ps2000_ready\(\)](#)^[31]
7. Transfer the block of data from the oscilloscope using [ps2000_get_times_and_values\(\)](#)^[22]
8. Display the data.
9. Repeat steps 6 to 8 as necessary.
10. Stop the oscilloscope using [ps2000_stop\(\)](#)^[53]

3.3.8.6 Streaming mode

Streaming mode is an alternative to [block mode](#)^[7] that can capture data without gaps between blocks.

In streaming mode, the computer prompts the oscilloscope to start collecting data. The data is then transferred back to the PC without being stored in the oscilloscope's memory. Data can be sampled with a period between 1 μ s or less and 60 s, and the maximum number of samples is limited only by the amount of free space on the PC's hard disk.

There are two varieties of streaming mode:

- [Compatible streaming mode](#)^[9]
- [Fast streaming mode](#)^[10]

3.3.8.7 Compatible streaming mode

Compatible streaming mode is a basic [streaming mode](#)^[9] that works at speeds from one sample per minute to a thousand samples per second.

The oscilloscope's driver transfers data to a computer program using either normal or windowed mode. In normal mode, any data collected since the last data transfer operation is returned in its entirety. Normal mode is useful if the computer program requires fresh data on every transfer. In windowed mode, a fixed number of samples is returned, where the oldest samples may have already been returned before. Windowed mode is useful when the program requires a constant time period of data.

Once the oscilloscope is collecting data in streaming mode, any setup changes (for example, changing a channel range or [AC/DC](#)^[57] setting) will cause a restart of the data stream. The driver can buffer up to 32 K samples of data per channel, but the user must ensure that the [ps2000_get_values\(\)](#)^[25] function is called frequently enough to avoid buffer overrun.

See [Using compatible streaming mode](#)^[9] for programming details.

Applicability	<p>Not available on PicoScope 2203, 2204 or 2205.</p> <p>Does not support triggering^[5].</p> <p>The ps2000_get_times_and_values()^[22] function always returns FALSE (0) in streaming mode.</p>
---------------	--

3.3.8.8 Using compatible streaming mode

This is the general procedure for reading and displaying data in [compatible streaming mode](#)^[9]:

1. Open the oscilloscope using [ps2000_open_unit\(\)](#)^[27]
2. Select channel ranges and AC/DC switches using [ps2000_set_channel\(\)](#)^[41]
3. Start the oscilloscope running using [ps2000_run_streaming\(\)](#)^[33]
4. Transfer the block of data from the oscilloscope using [ps2000_get_values\(\)](#)^[25]
5. Display the data.
6. Repeat steps 4 and 5 as necessary.
7. Stop the oscilloscope using [ps2000_stop\(\)](#)^[53]

3.3.8.9 Fast streaming mode

Fast streaming mode is an advanced [streaming mode](#)^[9] that can transfer data at speeds of a million samples per second or more, depending on the computer's performance. This makes it suitable for high-speed data acquisition, allowing you to capture very long data sets limited only by the computer's memory.

Fast streaming mode also provides [data aggregation](#)^[57], which allows your application to zoom in and out of the data with the minimum of effort.

Applicability	PicoScope 2203, 2204 and 2205 only.
	Works with triggering . ^[5]

See [Using fast streaming mode](#)^[10] for programming details.

3.3.8.10 Using fast streaming mode

This is the general procedure for reading and displaying data in [fast streaming mode](#):^[10]

1. Open the oscilloscope using [ps2000_open_unit\(\)](#).^[27]
2. Select channel ranges and AC/DC switches using [ps2000_set_channel\(\)](#).^[41]
3. Set the trigger using [ps2000_set_trigger\(\)](#).^[51]
4. Start the oscilloscope running using [ps2000_run_streaming_ns\(\)](#).^[34]
5. Get a block of data from the oscilloscope using [ps2000_get_streaming_last_values\(\)](#).^[16]
6. Display or process the data.
7. If required, check for overview buffer overruns by calling [ps2000_overview_buffer_status\(\)](#).^[30]
8. Repeat steps 5 to 7 as necessary or until auto_stop is TRUE.
9. Stop fast streaming using [ps2000_stop\(\)](#).^[53]
10. Retrieve any part of the data at any time scale by calling [ps2000_get_streaming_values\(\)](#).^[17]
11. If you require raw data, retrieve it by calling [ps2000_get_streaming_values_no_aggregation\(\)](#).^[19]
12. Repeat steps 10 to 11 as necessary.
13. Close the oscilloscope by calling [ps2000_close_unit\(\)](#).^[14]

3.4 Programming examples

3.4.1 C

There are two C example programs: a simple GUI application, and a more comprehensive console mode program that demonstrates all of the facilities of the driver.

GUI example

The GUI example program is a generic Windows application - that is, it does not use Borland AppExpert or Microsoft AppWizard. To compile the program, create a new project for an Application containing the following files:

```
ps2000.c  
resource.h
```

and

```
ps2000bc.lib (Borland 32-bit applications)  
or  
ps2000.lib (Microsoft Visual C 32-bit applications)
```

The following files must be in the compilation directory:

```
ps2000.rch  
ps2000.h
```

and the following file must be in the same directory as the executable.

```
ps2000.dll
```

Console example

The console example program is also a generic Windows application - that is, it does not use Borland AppExpert or Microsoft AppWizard. To compile the program, create a new project for an Application containing the following files:

```
ps2000con.c
```

and

```
ps2000bc.lib (Borland 32-bit applications)  
or  
ps2000.lib (Microsoft Visual C 32-bit applications).
```

The following files must be in the compilation directory:

```
ps2000.h
```

and the following file must be in the same directory as the executable.

```
ps2000.dll
```

3.4.2 Visual Basic

The `Examples` subdirectory contains the following files:

```
ps2000.vbp - project file
ps2000.bas - procedure prototypes
ps2000.frm - form and program
```

Note: the functions that return a `TRUE/FALSE` value return 0 for `FALSE` and 1 for `TRUE`, whereas Visual Basic expects 65 535 for `TRUE`. To avoid this problem, check for `> 0` rather than `= TRUE`.

3.4.3 Delphi

The program `ps2000.dpr` demonstrates how to operate PicoScope 2000 Series PC Oscilloscopes. The file `ps2000.inc` contains procedure prototypes that you can include in your own programs. Other required files include:

```
ps2000.res
ps2000fm.dfm
ps2000fm.pas
```

This has been tested with Delphi version 3.

3.4.4 Excel

1. Load the spreadsheet `ps2000.xls`
2. Select Tools | Macro
3. Select GetData
4. Select Run

Note: the Excel Macro language is similar to Visual Basic. The functions which return a `TRUE/FALSE` value, return 0 for `FALSE` and 1 for `TRUE`, whereas Visual Basic expects 65 535 for `TRUE`. Check for `> 0` rather than `= TRUE`.

3.4.5 Agilent VEE

The example function `ps2000.vee` is in the `Examples` subdirectory. It uses procedures that are defined in `ps2000.vh`. It was tested using Agilent VEE version 5.

3.4.6 LabVIEW

The `ps2000.vi` example in the `Examples` subdirectory shows how to access the driver functions using LabVIEW. It was tested using version 6.1 of LabVIEW for Windows. To use the example, copy these files to your LabVIEW directory:

- `ps2000.vi`
- `open_unit.vi`
- `set_channel.vi`
- `setup_data_collection.vi`

You will also need

- `ps2000.dll`

from the installation directory.

3.5 Functions

3.5.1 Introduction

The PicoScope 2000 Series API exports the following functions for you to use in your own applications:

[ps2000_close_unit](#)^[14]
[ps2000_flash_led](#)^[15]
[ps2000_get_streaming_last_values](#)^[16]
[ps2000_get_streaming_values](#)^[17]
[ps2000_get_streaming_values_no_aggregation](#)^[19]
[ps2000_get_timebase](#)^[21]
[ps2000_get_times_and_values](#)^[22]
[ps2000_get_unit_info](#)^[24]
[ps2000_get_values](#)^[25]
[ps2000_last_button_press](#)^[26]
[ps2000_open_unit](#)^[27]
[ps2000_open_unit_async](#)^[28]
[ps2000_open_unit_progress](#)^[29]
[ps2000_overview_buffer_status](#)^[30]
[ps2000_ready](#)^[31]
[ps2000_run_block](#)^[32]
[ps2000_run_streaming](#)^[33]
[ps2000_run_streaming_ns](#)^[34]
[ps2000SetAdvTriggerChannelConditions](#)^[35]
[ps2000SetAdvTriggerChannelDirections](#)^[37]
[ps2000SetAdvTriggerChannelProperties](#)^[38]
[ps2000SetAdvTriggerDelay](#)^[40]
[ps2000_set_channel](#)^[41]
[ps2000_set_ets](#)^[42]
[ps2000_set_led](#)^[44]
[ps2000_set_light](#)^[43]
[ps2000SetPulseWidthQualifier](#)^[45]
[ps2000SetSigGenArbitrary](#)^[47]
[ps2000SetSigGenBuiltIn](#)^[49]
[ps2000_set_trigger](#)^[51]
[ps2000_set_trigger2](#)^[52]
[ps2000_stop](#)^[53]

The following user-defined function is also described here:

[my_get_overview_buffers](#)^[54]

3.5.2 `ps2000_close_unit`

```
short ps2000_close_unit (  
    short handle  
)
```

Shuts down a PicoScope 2000 Series oscilloscope.

Applicability	All modes
Arguments	<code>handle</code> : the handle, returned by ps2000_open_unit() ^[27] , of the oscilloscope being closed.
Returns	1: if a valid handle is passed. 0: if handle is not valid.

3.5.3

```
ps2000_flash_led  
    short ps2000_flash_led (  
        short handle  
    )
```

Flashes the LED on the front of the oscilloscope (or in the pushbutton, for the PicoScope 2104 and 2105 oscilloscopes) three times and returns within one second.

Applicability	All modes
Arguments	<code>handle</code> : the handle of the PicoScope 2000 Series oscilloscope.
Returns	1: if a valid handle is passed. 0: if handle is invalid.

3.5.4

ps2000_get_streaming_last_values

```
short ps2000_get_streaming_last_values (
    short handle
    GetOverviewBuffersMaxMin lpGetOverviewBuffersMaxMin
)
```

This function is used to collect the next block of values while [fast streaming](#)^[10] is running. You must have called [ps2000_run_streaming_ns\(\)](#)^[34] beforehand to set up fast streaming.

Applicability	<p>Fast streaming^[10] mode only.</p> <p>PicoScope 2203, 2204 and 2205 only.</p> <p>Not compatible with ETS^[8] triggering - function has no effect in ETS mode.</p>
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>lpGetOverviewBuffersMaxMin</code>: a pointer to the my_get_overview_buffers()^[54] callback function in your application that receives data from the streaming driver.</p>
Returns	<p>The actual number of data values returned per channel, which may be less than <code>max_samples</code> if streaming, where <code>max_samples</code> is a parameter passed to ps2000_run_streaming_ns()^[34].</p> <p>0: if one of the parameters is out of range.</p>

3.5.5 ps2000_get_streaming_values

```
unsigned long ps2000_get_streaming_values (  
    short      handle,  
    double     *start_time,  
    short      *pbuffer_a_max,  
    short      *pbuffer_a_min,  
    short      *pbuffer_b_max,  
    short      *pbuffer_b_min,  
    short      *pbuffer_c_max,  
    short      *pbuffer_c_min,  
    short      *pbuffer_d_max,  
    short      *pbuffer_d_min,  
    short      *overflow,  
    unsigned long *triggerAt,  
    short      *triggered,  
    unsigned long no_of_values,  
    unsigned long noOfSamplesPerAggregate  
)
```

This function is used after the driver has finished collecting data in [fast streaming mode](#).^[10] It allows you to retrieve data with different [aggregation](#)^[57] ratios, and thus zoom in to and out of any region of the data.

Before calling this function, first capture some data in fast streaming mode, stop fast streaming by calling [ps2000_stop\(\)](#),^[53] then allocate sufficient buffer space to receive the requested data. The function will store the data in your buffer with values in the range PS2000_MIN_VALUE to PS2000_MAX_VALUE. The special value PS2000_LOST_DATA is stored in the buffer when data could not be collected because of a buffer overrun. (See [Scaling](#)^[5] for more on data values.)

Each sample of aggregated data is created by processing a block of raw samples. The aggregated sample is stored as a pair of values: the minimum and the maximum values of the block.

Applicability	<p>Fast streaming^[10] mode only.</p> <p>PicoScope 2203, 2204 and 2205 only.</p> <p>Not compatible with ETS^[8] triggering - function has no effect in ETS mode.</p>
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>start_time</code>: the time in nanoseconds, relative to the trigger point, of the first data sample required.</p> <p><code>pbuffer_a_max</code>, <code>pbuffer_a_min</code>: pointers to two buffers into which the function will write the maximum and minimum aggregated sample values from channel A.</p> <p><code>pbuffer_b_max</code>, <code>pbuffer_b_min</code>: as above but for channel B (two-channel scopes only).</p> <p><code>pbuffer_c_max</code>, <code>pbuffer_c_min</code>, <code>pbuffer_d_max</code>, <code>pbuffer_d_min</code>: not used</p> <p><code>overflow</code>: on exit, the function writes a bit field here indicating whether the voltage on each of the input channels has overflowed:</p> <p style="padding-left: 40px;">Bit 0: Ch A overflow Bit 1: Ch B overflow</p> <p><code>triggerAt</code>: on exit, the function writes an index value here. This is the offset, from the start of the buffer, of the sample at the trigger reference point. It is valid only when <code>triggered</code> is TRUE.</p> <p><code>triggered</code>: a pointer to a Boolean indicating that a trigger has occurred and <code>triggerAt</code> is valid.</p> <p><code>no_of_values</code>: the number of values required.</p> <p><code>noOfSamplesPerAggregate</code>: the number of samples that the driver should combine to form each aggregated^[57] value pair. The pair consists of the maximum and minimum values of all the samples that were aggregated. For channel A, the minimum value is stored in the buffer pointed to by <code>pbuffer_a_min</code> and the maximum value in the buffer pointed to by <code>pbuffer_a_max</code>.</p>
Returns	<p>The number of values written to each buffer, if successful.</p> <p>0: if a parameter was out of range.</p>

3.5.6 ps2000_get_streaming_values_no_aggregation

```
unsigned long ps2000_get_streaming_values_no_aggregation (  
    short      handle,  
    double     *start_time,  
    short      *pbuffer_a,  
    short      *pbuffer_b,  
    short      *pbuffer_c,  
    short      *pbuffer_d,  
    short      *overflow,  
    unsigned long *triggerAt,  
    short      *trigger,  
    unsigned long no_of_values  
)
```

This function retrieves raw streaming data from the driver's data store after [fast streaming](#)^[10] has stopped.

Before calling the function, capture some data using fast streaming, stop streaming using [ps2000_stop\(\)](#),^[53] and then allocate sufficient buffer space to receive the requested data. The function will store the data in your buffer with values in the range PS2000_MIN_VALUE to PS2000_MAX_VALUE. The special value PS2000_LOST_DATA is stored in the buffer when data could not be collected because of a buffer overrun. (See [Scaling](#)^[5] for more details of data values.)

Applicability	<p>Fast streaming^[10] mode only.</p> <p>PicoScope 2203, 2204 and 2205 only.</p> <p>Not compatible with ETS^[8] triggering - has no effect in ETS mode.</p>
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>start_time</code>: the time in nanoseconds of the first data sample required.</p> <p><code>pbuffer_a</code>, <code>pbuffer_b</code>: pointers to buffers into which the function will write the raw sample values from channels A (all scopes) and B (two-channel scopes only).</p> <p><code>pbuffer_c</code>, <code>pbuffer_d</code>: not used.</p> <p><code>overflow</code>: on exit, the function will write a bit field here indicating whether the voltage on each of the input channels has overflowed. Bit 0 is the LSB. The bit assignments are as follows:</p> <p style="padding-left: 40px;">Bit 0 - Ch A overflow Bit 1 - Ch B overflow</p> <p><code>triggerAt</code>: on exit, the function writes an index into the buffers here. The index is the number of the the sample at the trigger reference point. It is valid only when <code>trigger</code> is TRUE.</p> <p><code>trigger</code>: on exit, the function writes a Boolean here indicating that a trigger has occurred and <code>triggerAt</code> is valid.</p> <p><code>no_of_values</code>: the number of values required.</p>
Returns	<p>The number of values written to each buffer, if successful. 0: if a parameter was out of range.</p>

3.5.7

```
ps2000_get_timebase
short ps2000_get_timebase (
    short handle,
    short timebase,
    long no_of_samples,
    long *time_interval,
    short *time_units,
    short oversample,
    long *max_samples
)
```

This function discovers which [timebases](#)^[58] are available on the oscilloscope. You should set up the channels using [ps2000_set_channel\(\)](#)^[41] and, if required, [ETS](#)^[8] mode using [ps2000_set_ets\(\)](#)^[42] first. Then call this function with increasing values of `timebase`, starting from 0, until you find a timebase with a sampling interval and sample count close enough to your requirements.

Applicability	All modes
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>timebase</code>: a code between 0 and the maximum timebase (depending on the oscilloscope). Timebase 0 is the fastest timebase. Each successive timebase has twice the sampling interval of the previous one.</p> <p><code>no_of_samples</code>: the number of samples that you require. The function uses this value to calculate the most suitable time unit to use.</p> <p><code>time_interval</code>: on exit, this location will contain the time interval between readings at the selected timebase. If <code>time_interval</code> is NULL, the function will write nothing.</p> <p><code>time_units</code>: on exit, this location will contain an enumerated type indicating the most suitable unit for expressing sample times. You should pass this value to ps2000_get_times_and_values()^[22]. If <code>time_units</code> is null, the function will write nothing.</p> <p><code>oversample</code>: the amount of oversample required. For example, an oversample of 4 results in a <code>time_interval</code> 4 times larger and a <code>max_samples</code> 4 times smaller. At the same time it increases the effective resolution by one bit. See Oversampling^[5] for more details.</p> <p><code>max_samples</code>: on exit, this location contains the maximum number of samples available. The number may vary depending on the number of channels enabled, the timebase chosen and the oversample multiplier selected. If <code>max_samples</code> is null, the function will write nothing.</p>
Returns	<p>1: if all parameters are in range.</p> <p>0: on error.</p>

3.5.8

ps2000_get_times_and_values

```
long ps2000_get_times_and_values (  
    short handle  
    long *times,  
    short *buffer_a,  
    short *buffer_b,  
    short *buffer_c,  
    short *buffer_d,  
    short *overflow,  
    short time_units,  
    long no_of_values  
)
```

This function is used to get values and times in [block mode](#)^[7] after calling [ps2000_run_block\(\)](#)^[32].

<p>Applicability</p>	<p>Block mode^[7] only. It will not return any valid times if the oscilloscope is in streaming mode^[9].</p> <p>Essential for ETS^[8] operation.</p>
<p>Arguments</p>	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>times</code>: a pointer to a buffer for the sample times in <code>time_units</code>. Each time is the interval between the trigger event and the corresponding sample. Times before the trigger event are negative, and times after the trigger event are positive.</p> <p><code>buffer_a</code>, <code>buffer_b</code>: pointers to buffers that receive data from the channels A and B. A pointer will not be used if the oscilloscope is not collecting data from that channel. If a pointer is NULL, nothing will be written to it.</p> <p><code>buffer_c</code>, <code>buffer_d</code>: not used.</p> <p><code>overflow</code>: a bit pattern indicating whether an overflow has occurred and, if so, on which channel. Bit 0 is the LSB. The bit assignments are as follows: Bit 0 - Ch A overflow Bit 1 - Ch B overflow</p> <p><code>time_units</code>: can be one of the following: PS2000_FS (0), femtoseconds, PS2000_PS (1), picoseconds, PS2000_NS (2), nanoseconds [default] PS2000_US (3), microseconds, PS2000_MS (4), milliseconds, PS2000_S (5), seconds</p> <p><code>no_of_values</code>: the number of data points to return. In streaming mode, this is the maximum number of values to return.</p>
<p>Returns</p>	<p>The actual number of data values per channel returned, which may be less than <code>no_of_values</code> if streaming.</p> <p>0: if one or more of the parameters are out of range, or if the times will overflow with the <code>time_units</code> requested (use ps2000_get_timebase()^[21] to acquire the most suitable <code>time_units</code>), or if the oscilloscope is in streaming mode.</p>

```

3.5.9 ps2000_get_unit_info
      short ps2000_get_unit_info (
          short handle,
          char *string,
          short string_length,
          short line
      )

```

This function writes oscilloscope information to a character string. If the oscilloscope failed to open, only `line` types 0 and 6 are available to explain why the last open unit call failed.

Applicability	All modes
Arguments	<p><code>handle</code>: the handle of the oscilloscope from which information is required. If an invalid handle is passed, the error code from the last oscilloscope that failed to open is returned.</p> <p><code>string</code>: a pointer to the character string buffer in the calling function where the function will write the oscilloscope information string selected with <code>line</code>. If <code>string</code> is <code>NULL</code>, no information will be written.</p> <p><code>string_length</code>: the length of the character string buffer. If the string is not long enough to accept all of the information, only the first <code>string_length</code> characters are returned.</p> <p><code>line</code>: an enumerated type specifying what information is required from the driver.</p>
Returns	The length of the string written to the <code>string</code> buffer. 0: if one of the parameters is out of range or <code>string</code> is <code>NULL</code> .

<code>line</code>	String returned	Example
0 PS2000_DRIVER_VERSION	The version number of the DLL used by the oscilloscope driver.	"1, 0, 0, 2"
1 PS2000_USB_VERSION	The type of USB connection that is being used to connect the oscilloscope to the computer.	"1.1" or "2.0"
2 PS2000_HARDWARE_VERSION	The hardware version of the attached oscilloscope.	"1"
3 PS2000_VARIANT_INFO	The variant of PicoScope 2000 PC Oscilloscope that is attached to the computer.	"2203"
4 PS2000_BATCH_AND_SERIAL	The batch and serial number of the oscilloscope.	"CMY66/052"
5 PS2000_CAL_DATE	The calibration date of the oscilloscope.	"14Jan08"
6 PS2000_ERROR_CODE	One of the Error codes ⁵⁶ .	"4"

3.5.10 ps2000_get_values

```

long ps2000_get_values (
    short handle
    short *buffer_a,
    short *buffer_b,
    short *buffer_c,
    short *buffer_d,
    short *overflow,
    long no_of_values
)
    
```

This function is used to get values in [compatible streaming mode](#)^[9] after calling [ps2000_run_streaming\(\)](#)^[33], or in [block mode](#)^[7] after calling [ps2000_run_block\(\)](#)^[32].

<p>Applicability</p>	<p>Compatible streaming mode^[9] and block mode^[7] only.</p> <p>Does nothing if ETS^[8] triggering is enabled. Use ps2000_get_times_and_values()^[22] instead.</p> <p>Do not use in fast streaming mode^[10]. Use ps2000_get_streaming_last_values()^[18] instead.</p>
<p>Arguments</p>	<p>handle: the handle of the required oscilloscope.</p> <p>buffer_a, buffer_b: pointers to the buffers that receive data from the specified channels (A and B). A pointer is not used if the oscilloscope is not collecting data from that channel. If a pointer is NULL, nothing will be written to it.</p> <p>buffer_c, buffer_d: not used.</p> <p>overflow: on exit, contains a bit pattern indicating whether an overflow has occurred and, if so, on which channel. Bit 0 is the least significant bit. The bit assignments are as follows: Bit 0 - Ch A overflow Bit 1 - Ch B overflow</p> <p>no_of_values: the number of data points to return. In streaming mode, this is the maximum number of values to return.</p>
<p>Returns</p>	<p>The actual number of data values per channel returned, which may be less than <code>no_of_values</code> if streaming.</p> <p>0: if one of the parameters is out of range or the oscilloscope is not in a suitable mode.</p>

3.5.11 `ps2000_last_button_press`

```
short ps2000_last_button_press (  
    short handle  
)
```

This function returns the last registered state of the pushbutton on the PicoScope 2104 or 2105 PC Oscilloscope and then resets the status to zero.

Applicability	PicoScope 2104 and 2105 only
Arguments	<code>handle</code> : handle of the oscilloscope
Returns	0: no button press registered 1: short button press registered 2: long button press registered

3.5.12 ps2000_open_unit

```
short ps2000_open_unit (  
    void  
)
```

This function opens a PicoScope 2000 Series oscilloscope. The driver can support up to four oscilloscopes.

Applicability	All modes
Arguments	None
Returns	-1: if the oscilloscope fails to open. 0: if no oscilloscope is found. >0 (oscilloscope handle): if the oscilloscope opened. Use this as the handle argument for all subsequent API calls for this oscilloscope.

3.5.13 `ps2000_open_unit_async`

```
short ps2000_open_unit_async (  
    void  
)
```

This function opens a PicoScope 2000 Series oscilloscope without waiting for the operation to finish. You can find out when it has finished by periodically calling [ps2000_open_unit_progress\(\)](#) until that function returns a non-zero value and a valid oscilloscope handle.

The driver can support up to four oscilloscopes.

Applicability	All modes
Arguments	None
Returns	0: if there is a previous open operation in progress. 1: if the call has successfully initiated an open operation.

3.5.14 `ps2000_open_unit_progress`

```
short ps2000_open_unit_progress (
    short *handle,
    short *progress_percent
)
```

This function checks on the progress of [ps2000_open_unit_async\(\)](#)^[28].

Applicability	All modes. Use only with ps2000_open_unit_async() ^[28] .
Arguments	<code>handle</code> : a pointer to where the function should store the handle of the opened oscilloscope. 0 if no oscilloscope is found or the oscilloscope fails to open, handle of oscilloscope (valid only if function returns 1) <code>progress_percent</code> : a pointer to an estimate of the progress towards opening the oscilloscope. The function will write a value from 0 to 100, where 100 implies that the operation is complete.
Returns	1: if the driver successfully opens the oscilloscope 0: if opening still in progress -1: if the oscilloscope failed to open or was not found

```

3.5.15 ps2000_overview_buffer_status
    short ps2000_overview_buffer_status (
        short handle,
        short *previous_buffer_overrun
    )

```

This function indicates whether or not the overview buffers used by [ps2000_run_streaming_ns\(\)](#)^[34] have overrun. If an overrun occurs, you can choose to increase the `overview_buffer_size` argument that you pass in the next call to [ps2000_run_streaming_ns\(\)](#)^[34].

Applicability	<p>Fast streaming^[10] mode only.</p> <p>PicoScope 2203, 2204 and 2205 only.</p> <p>Not compatible with ETS^[8] triggering - function has no effect in ETS mode.</p>
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>previous_buffer_overrun</code>: a pointer to a Boolean indicating whether the overview buffers have overrun. The function will write a non-zero value to indicate a buffer overrun.</p>
Returns	<p>0: if the function was successful.</p> <p>1: if the function failed due to an invalid handle.</p>

3.5.16 `ps2000_ready`

```
short ps2000_ready (  
    short handle  
)
```

This function checks to see if the oscilloscope has finished the last data collection operation.

Applicability	Block mode ^[7] only. Does nothing if the oscilloscope is in streaming mode ^[9] .
Arguments	<code>handle</code> : the handle of the required oscilloscope.
Returns	1: if ready. The oscilloscope has collected a complete block of data or the auto trigger timeout has been reached. 0: if not ready. An invalid handle was passed, or the oscilloscope is in streaming mode, or the oscilloscope is still collecting data in block mode. -1: if the oscilloscope is not attached. The USB transfer failed, indicating that the oscilloscope may well have been unplugged.

3.5.17 ps2000_run_block

```

short ps2000_run_block (
    short handle,
    long  no_of_samples,
    short timebase,
    short oversample,
    long  *time_indisposed_ms
)

```

This function tells the oscilloscope to start collecting data in [block mode](#)^[7].

Applicability	Block mode ^[7] only.
Arguments	<p><code>handle</code>: the oscilloscope of the required oscilloscope.</p> <p><code>no_of_samples</code>: the number of samples to return.</p> <p><code>timebase</code>: a code between 0 and the maximum timebase available (consult the driver header file). Timebase 0 gives the maximum sample rate available, timebase 1 selects a sample rate half as fast, timebase 2 is half as fast again and so on. For the maximum sample rate, see the specifications for your oscilloscope. The number of channels enabled may affect the availability of the fastest timebases.</p> <p><code>oversample</code>: the oversampling factor, a number between 1 and 256. See Oversampling^[5] for details.</p> <p><code>time_indisposed_ms</code>: a pointer to the approximate time, in milliseconds, that the ADC will take to collect data. If a trigger is set, it is the amount of time the ADC takes to collect a block of data after a trigger event, calculated as (sample interval) x (number of points required). The actual time may differ from computer to computer, depending on how quickly the computer can respond to I/O requests.</p>
Returns	<p>0: if one of the parameters is out of range.</p> <p>1: if successful.</p>

3.5.18 `ps2000_run_streaming`

```

short ps2000_run_streaming (
    short handle,
    short sample_interval_ms,
    long max_samples,
    short windowed
)

```

This function tells the oscilloscope to start collecting data in [compatible streaming mode](#)^[9]. If this function is called when a trigger has been enabled, the trigger settings will be ignored.

For streaming with the PicoScope 2203, 2204 and 2205 variants, use [ps2000_run_streaming_ns\(\)](#)^[34] instead.

Applicability	PicoScope 2202, 2104 and 2105 only.
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>sample_interval_ms</code>: the time interval, in milliseconds, between data points. This can be no shorter than 1 ms.</p> <p><code>max_samples</code>: the maximum number of samples that the driver is to store. This can be no greater than 60 000. It is the application's responsibility to retrieve data before the oldest values are overwritten.</p> <p><code>windowed</code>: if this is 0, only the values taken since the last call to ps2000_get_values()^[25] are returned. If this is 1, the number of values requested by ps2000_get_values()^[25] are returned, even if they have already been read by ps2000_get_values()^[25].</p>
Returns	<p>1: if streaming has been enabled correctly.</p> <p>0: if a problem occurred or a value was out of range.</p>

3.5.19 ps2000_run_streaming_ns

```

short ps2000_run_streaming_ns (
    short          handle,
    unsigned long  sample_interval,
    PS2000_TIME_UNITS time_units,
    unsigned long  max_samples,
    short         auto_stop,
    unsigned long  noOfSamplesPerAggregate,
    unsigned long  overview_buffer_size
)

```

This function tells the oscilloscope to start collecting data in [fast streaming mode](#)^[10]. It returns immediately without waiting for data to be captured. After calling it, you should next call [ps2000_get_streaming_last_values\(\)](#)^[16] to copy the data to your application's buffer.

Applicability	PicoScope 2203, 2204 and 2205 only.
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>sample_interval</code>: the time interval, in <code>time_units</code>, between data points.</p> <p><code>time_units</code>: the units in which <code>sample_interval</code> is measured.</p> <p><code>max_samples</code>: the maximum number of samples that the driver should store from each channel. Your computer must have enough physical memory for this many samples, multiplied by the number of channels in use, multiplied by the number of bytes per sample.</p> <p><code>auto_stop</code>: a Boolean to indicate whether streaming should stop automatically when <code>max_samples</code> is reached. Set to any non-zero value for <code>TRUE</code>.</p> <p><code>noOfSamplesPerAggregate</code>: the number of incoming samples that the driver will merge together (or aggregate: see aggregation^[57]) to create each value pair passed to the application. The value must be between 1 and <code>max_samples</code>.</p> <p><code>overview_buffer_size</code>: the size of the overview buffers, temporary buffers used by the driver to store data before passing it to your application. You can check for overview buffer overruns using the ps2000_overview_buffer_status()^[30] function and adjust the overview buffer size if necessary. We recommend using an initial value of 15,000 samples.</p>
Returns	<p>1: if streaming has been enabled correctly.</p> <p>0: if a problem occurred or a value was out of range.</p>

3.5.20 ps2000SetAdvTriggerChannelConditions

```

short ps2000SetAdvTriggerChannelConditions(
    short          handle,
    PS2000_TRIGGER_CONDITIONS *conditions,
    short          nConditions
)

```

This function sets up trigger conditions on the scope's inputs. The trigger is defined by a [PS2000_TRIGGER_CONDITIONS](#) structure.

Applicability	PicoScope 2205 only
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>conditions</code>: a pointer to a PS2000_TRIGGER_CONDITIONS structure specifying the conditions that should be applied to the current trigger channel. If NULL, triggering is switched off.</p> <p><code>nConditions</code>: should be set to 1 if <code>conditions</code> is non-null, otherwise 0.</p>
Returns	<p>0: if unsuccessful, or if one or more of the arguments are out of range.</p> <p>1: if successful.</p>

3.5.20.1 PS2000_TRIGGER_CONDITIONS structure

A structure of this type is passed to [ps2000SetAdvTriggerChannelConditions\(\)](#)^[35] in the `conditions` argument to specify the trigger conditions, and is defined as follows: -

```
typedef struct tPS2000TriggerConditions
{
    PS2000_TRIGGER_STATE channelA;
    PS2000_TRIGGER_STATE channelB;
    PS2000_TRIGGER_STATE channelC;
    PS2000_TRIGGER_STATE channelD;
    PS2000_TRIGGER_STATE external;
    PS2000_TRIGGER_STATE pulseWidthQualifier;
} PS2000_TRIGGER_CONDITIONS;
```

Applicability	See ps2000SetAdvTriggerChannelConditions() ^[35] .
Members	<p><code>channelA</code>, <code>channelB</code>: the type of condition that should be applied to each channel. Use these constants: -</p> <ul style="list-style-type: none"> <code>CONDITION_DONT_CARE</code> (0) <code>CONDITION_TRUE</code> (1) <code>CONDITION_FALSE</code> (2) <p><code>channelC</code>, <code>channelD</code>: not used</p> <p><code>external</code>: not used</p> <p><code>pulseWidthQualifier</code>: the type of condition to apply to the pulse width qualifier. Choose from the same list of constants given under <code>channelA</code>, <code>channelB</code>.</p>

Remarks

The channels that are set to `CONDITION_TRUE` or `CONDITION_FALSE` must all meet their conditions simultaneously to produce a trigger. Channels set to `CONDITION_DONT_CARE` are ignored.

The oscilloscope can use only a single input channel (either channel A or channel B) for the trigger source. Therefore you may define `CONDITION_TRUE` or `CONDITION_FALSE` for only one of these channels at a time. You can, optionally, set up the pulse width qualifier in combination with one of the input channels.

3.5.21 ps2000SetAdvTriggerChannelDirections

```
short ps2000SetAdvTriggerChannelDirections(
    short handle,
    PS2000_THRESHOLD_DIRECTION channelA,
    PS2000_THRESHOLD_DIRECTION channelB,
    PS2000_THRESHOLD_DIRECTION channelC,
    PS2000_THRESHOLD_DIRECTION channelD,
    PS2000_THRESHOLD_DIRECTION ext
)
```

This function sets the direction of the trigger for each channel.

Applicability	PicoScope 2205 only
Arguments	<p>handle: the handle of the required oscilloscope</p> <p>channelA, channelB: specify the direction in which the signal must pass through the threshold to activate the trigger. The allowable values for a PS2000_THRESHOLD_DIRECTION variable are listed in the table below.</p> <p>channelC, channelD: not used</p> <p>ext: not used</p>
Returns	<p>0: if unsuccessful, or if one or more of the arguments are out of range.</p> <p>1: if successful.</p>

PS2000_THRESHOLD_DIRECTION constants

ABOVE	for gated triggers: above a threshold
BELOW	for gated triggers: below a threshold
RISING	for threshold triggers: rising edge
FALLING	for threshold triggers: falling edge
RISING_OR_FALLING	for threshold triggers: either edge
INSIDE	for window-qualified triggers: inside window
OUTSIDE	for window-qualified triggers: outside window
ENTER	for window triggers: entering the window
EXIT	for window triggers: leaving the window
ENTER_OR_EXIT	for window triggers: either entering or leaving the window
NONE	no trigger

3.5.22 ps2000SetAdvTriggerChannelProperties

```

short ps2000SetAdvTriggerChannelProperties(
    short          handle,
    PS2000_TRIGGER_CHANNEL_PROPERTIES *channelProperties,
    short          nChannelProperties,
    long           autoTriggerMilliseconds
)

```

This function is used to enable or disable triggering and set its parameters.

Applicability	PicoScope 2205 only
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>channelProperties</code>: a pointer to a PS2000_TRIGGER_CHANNEL_PROPERTIES structure describing the requested properties. If NULL, triggering is switched off.</p> <p><code>nChannelProperties</code>: should be set to 1 if <code>channelProperties</code> is non-null, otherwise 0.</p> <p><code>autoTriggerMilliseconds</code>: the time in milliseconds for which the oscilloscope will wait before collecting data if no trigger event occurs. If this is set to zero, the oscilloscope will wait indefinitely for a trigger.</p>
Returns	<p>0: if unsuccessful, or if one or more of the arguments are out of range.</p> <p>1: if successful.</p>

3.5.22.1 PS2000_TRIGGER_CHANNEL_PROPERTIES structure

A structure of this type is passed to [ps2000SetAdvTriggerChannelProperties\(\)](#)^[38] in the `channelProperties` argument to specify the trigger mechanism, and is defined as follows: -

```
typedef struct tPS2000TriggerChannelProperties
{
    short          thresholdMajor;
    short          thresholdMinor;
    unsigned short hysteresis;
    short          channel;
    PS2000_THRESHOLD_MODE thresholdMode;
} PS2000_TRIGGER_CHANNEL_PROPERTIES
```

Applicability	See ps2000SetAdvTriggerChannelProperties() ^[38]
Members	<p><code>thresholdMajor</code>: the upper threshold at which the trigger event is to take place. This is scaled in 16-bit ADC counts at the currently selected range for that channel.</p> <p><code>thresholdMinor</code>: the lower threshold at which the trigger event is to take place. This is scaled in 16-bit ADC counts at the currently selected range for that channel.</p> <p><code>hysteresis</code>: the hysteresis that the trigger has to exceed before it will fire. It is scaled in 16-bit counts.</p> <p><code>channel</code>: the channel to which the properties apply.</p> <p><code>thresholdMode</code>: either a level or window trigger. Use one of these constants:</p> <pre> LEVEL (0) WINDOW (1)</pre>

3.5.23 ps2000SetAdvTriggerDelay

```

short ps2000SetAdvTriggerDelay(
    short      handle,
    unsigned long delay,
    float      preTriggerDelay
)

```

This function sets the post-trigger delay, which causes capture to start a defined time after the trigger event.

Applicability	All modes. PicoScope 2205 only.
Arguments	<code>handle</code> : the handle of the required oscilloscope <code>delay</code> : specifies the delay, as a percentage of the requested number of data points, between the trigger event and the start of the block. It should be in the range -100% to +100%. For example, 0% means that the trigger event is at the first data value in the block, and -50% means that it is in the middle of the block.
Returns	0: if unsuccessful, or if one or more of the arguments are out of range. 1: if successful.

3.5.24 ps2000_set_channel

```
short ps2000_set_channel (
    short handle,
    short channel,
    short enabled,
    short dc,
    short range
)
```

Specifies if a channel is to be enabled, the [AC/DC coupling](#)⁴ mode and the input range.

Applicability	All modes
Arguments	<p>handle: the handle of the required oscilloscope.</p> <p>channel: an enumerated type specifying the channel. Use PS2000_CHANNEL_A (0) or PS2000_CHANNEL_B (1).</p> <p>enabled: specifies if the channel is active: TRUE = active FALSE = inactive</p> <p>dc: specifies the AC/DC coupling⁴ mode: TRUE: DC coupling FALSE: AC coupling</p> <p>range: a code between 1 and 10. See the table below, but note that each oscilloscope variant supports only a subset of these ranges.</p>
Returns	<p>0: if unsuccessful, or if one or more of the arguments are out of range</p> <p>1: if successful</p>

Code	Enumeration	Range
1	PS2000_20MV	±20 mV
2	PS2000_50MV	±50 mV
3	PS2000_100MV	±100 mV
4	PS2000_200MV	±200 mV
5	PS2000_500MV	±500 mV
6	PS2000_1V	±1 V
7	PS2000_2V	±2 V
8	PS2000_5V	±5 V
9	PS2000_10V	±10 V
10	PS2000_20V	±20 V

```

3.5.25 ps2000_set_ets
    long ps2000_set_ets (
        short handle,
        short mode,
        short ets_cycles,
        short ets_interleave
    )

```

This function is used to enable or disable [ETS](#) (equivalent time sampling) and to set the ETS parameters.

Applicability	Not PicoScope 2202.
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>mode</code>:</p> <ul style="list-style-type: none"> <code>PS2000_ETS_OFF (0)</code> - disables ETS <code>PS2000_ETS_FAST (1)</code> - enables ETS and provides <code>ets_cycles</code> cycles of data, which may contain data from previously returned cycles <code>PS2000_ETS_SLOW (2)</code> - enables ETS and provides fresh data every <code>ets_cycles</code> cycles. <code>PS2000_ETS_SLOW</code> takes longer to provide each data set, but the data sets are more stable and unique <p><code>ets_cycles</code>: the number of cycles to store. The computer can then select <code>ets_interleave</code> cycles to give the most uniform spread of samples. <code>ets_cycles</code> should be between two and five times the value of <code>ets_interleave</code>.</p> <p><code>ets_interleave</code>: the number of ETS interleaves to use. If the sample time is 20 ns and the interleave 10, the approximate time per sample will be 2 ns.</p>
Returns	The effective sample time in picoseconds, if ETS is enabled. 0: if ETS is disabled or one of the parameters is out of range.

3.5.26 `ps2000_set_light`

```
short ps2000_set_light (  
    short handle,  
    short state  
)
```

This function controls the white light that illuminates the probe tip on a handheld oscilloscope.

Applicability	PicoScope 2104 and 2105 handheld oscilloscopes only.
Arguments	<code>handle</code> : handle of the oscilloscope <code>state</code> : 0: light off 1: light on
Returns	0: the function failed, for example if a PicoScope 2000 Series oscilloscope was not found. <> 0: success.

```
3.5.27 ps2000_set_led
short ps2000_set_led (
    short handle,
    short state
)
```

This function turns the LED on the oscilloscope on and off, and controls its colour.

Applicability	PicoScope 2104 and 2105 handheld oscilloscopes only.
Arguments	<code>handle</code> : handle of the oscilloscope <code>state</code> : 3: off 1: red 2: green
Returns	0: the function failed, for example if a PicoScope 2000 Series oscilloscope was not found. <> 0: success.

3.5.28 ps2000SetPulseWidthQualifier

```

short ps2000SetPulseWidthQualifier(
    short          handle,
    PS2000_PWQ_CONDITIONS *conditions,
    short          nConditions,
    PS2000_THRESHOLD_DIRECTION direction,
    unsigned long  lower,
    unsigned long  upper,
    PS2000_PULSE_WIDTH_TYPE type
)
    
```

This function sets up pulse width qualification, which can be used on its own for pulse width triggering or combined with other triggering to produce more complex triggers. The pulse width qualifier is set by defining a `conditions` structure.

Applicability	All modes PicoScope 2205 only										
Arguments	<p><code>handle</code>: the handle of the required oscilloscope.</p> <p><code>conditions</code>: a pointer to a PS2000_PWQ_CONDITIONS ⁴⁶ structure specifying the conditions that should be applied to the trigger channel. If <code>conditions</code> is NULL then the pulse width qualifier is not used.</p> <p><code>nConditions</code>: should be set to 1 if <code>conditions</code> is non-null, otherwise 0.</p> <p><code>direction</code>: the direction of the signal required to trigger the pulse.</p> <p><code>lower</code>: the lower limit of the pulse width counter.</p> <p><code>upper</code>: the upper limit of the pulse width counter. This parameter is used only when the <code>type</code> is set to <code>PW_TYPE_IN_RANGE</code> or <code>PW_TYPE_OUT_OF_RANGE</code>.</p> <p><code>type</code>: the pulse width type, one of these constants:</p> <table border="0" data-bbox="542 1478 1388 1736"> <tr> <td><code>PW_TYPE_NONE</code></td> <td>do not use the pulse width qualifier</td> </tr> <tr> <td><code>PW_TYPE_LESS_THAN</code></td> <td>pulse width less than lower</td> </tr> <tr> <td><code>PW_TYPE_GREATER_THAN</code></td> <td>pulse width greater than lower</td> </tr> <tr> <td><code>PW_TYPE_IN_RANGE</code></td> <td>pulse width between lower and upper</td> </tr> <tr> <td><code>PW_TYPE_OUT_OF_RANGE</code></td> <td>pulse width not between lower and upper</td> </tr> </table>	<code>PW_TYPE_NONE</code>	do not use the pulse width qualifier	<code>PW_TYPE_LESS_THAN</code>	pulse width less than lower	<code>PW_TYPE_GREATER_THAN</code>	pulse width greater than lower	<code>PW_TYPE_IN_RANGE</code>	pulse width between lower and upper	<code>PW_TYPE_OUT_OF_RANGE</code>	pulse width not between lower and upper
<code>PW_TYPE_NONE</code>	do not use the pulse width qualifier										
<code>PW_TYPE_LESS_THAN</code>	pulse width less than lower										
<code>PW_TYPE_GREATER_THAN</code>	pulse width greater than lower										
<code>PW_TYPE_IN_RANGE</code>	pulse width between lower and upper										
<code>PW_TYPE_OUT_OF_RANGE</code>	pulse width not between lower and upper										
Returns	0: if unsuccessful, or if one or more of the arguments are out of range. 1: if successful.										

3.5.28.1 PS2000_PWQ_CONDITIONS structure

A structure of this type is passed to [ps2000SetPulseWidthQualifier\(\)](#)^[45] in the `conditions` argument to specify the pulse-width qualifier conditions, and is defined as follows: -

```
typedef struct tPS2000PwqConditions
{
    PS2000_TRIGGER_STATE channelA;
    PS2000_TRIGGER_STATE channelB;
    PS2000_TRIGGER_STATE channelC;
    PS2000_TRIGGER_STATE channelD;
    PS2000_TRIGGER_STATE external;
} PS2000_PWQ_CONDITIONS
```

Applicability	Pulse-width-qualified triggering
Members	<p><code>channelA</code>, <code>channelB</code>: the type of condition that should be applied to each channel. Choose from these constants:</p> <pre>CONDITION_DONT_CARE (0) CONDITION_TRUE (1) CONDITION_FALSE (2)</pre> <p><code>channelC</code>, <code>channelD</code>: not used</p> <p><code>external</code>: not used</p>

3.5.29 ps2000SetSigGenArbitrary

```
short ps2000_set_sig_gen_arbitrary (  
    short          handle,  
    long           offsetVoltage,  
    unsigned long  pkToPk,  
    unsigned long  startDeltaPhase,  
    unsigned long  stopDeltaPhase,  
    unsigned long  deltaPhaseIncrement,  
    unsigned long  dwellCount,  
    unsigned char  *arbitraryWaveform,  
    long           arbitraryWaveformSize,  
    PS2000_SWEEP_TYPE sweepType,  
    unsigned long  sweeps  
)
```

This function instructs the signal generator to produce an arbitrary waveform.

The arbitrary waveform generator uses direct digital synthesis (DDS). It maintains a 32-bit phase counter that indicates the present location in the waveform. The top 11 bits of the counter are used as an index into a buffer containing the arbitrary waveform.

The generator steps through the waveform by adding a "delta phase" between 1 and $2^{32}-1$ to the phase counter every 50 ns. If the delta phase is constant, then the generator produces a waveform at a constant frequency. It is also possible to sweep the frequency by continually modifying the delta phase. This is done by setting up a "delta phase increment" which is added to the delta phase at specified intervals.

Applicability	<p>All modes</p> <p>PicoScope 2203, 2204 and 2205 only</p>
Arguments	<p><code>handle</code>: the handle of the required oscilloscope</p> <p><code>offsetVoltage</code>: the voltage offset, in microvolts, to be applied to the waveform</p> <p><code>pkToPk</code>: the peak-to-peak voltage, in microvolts, of the waveform signal</p> <p><code>startDeltaPhase</code>: the initial value added to the phase counter as the generator begins to step through the waveform buffer</p> <p><code>stopDeltaPhase</code>: the final value added to the phase counter before the generator restarts or reverses the sweep</p> <p><code>deltaPhaseIncrement</code>: the amount added to the delta phase value every time the <code>dwellCount</code> period expires. This determines the amount by which the generator sweeps the output frequency in each dwell period.</p> <p><code>dwellCount</code>: the time, in 50 ns steps, between successive additions of <code>deltaPhaseIncrement</code> to the delta phase counter. This determines the rate at which the generator sweeps the output frequency.</p> <p><code>arbitraryWaveform</code>: a pointer to a buffer that holds the waveform pattern as a set of samples equally spaced in time.</p> <p><code>arbitraryWaveformSize</code>: the size of the arbitrary waveform buffer.</p> <p><code>sweepType</code>: determines whether the <code>startDeltaPhase</code> is swept up to the <code>stopDeltaPhase</code>, or down to it, or repeatedly swept up and down. Use one of the following values:</p> <ul style="list-style-type: none"> UP DOWN UPDOWN DOWNUP <p><code>sweeps</code>: the number of times to sweep the frequency after a trigger event, according to <code>sweepType</code>.</p>
Returns	<p>0: if successful.</p> <p>Error code: if failed</p>

3.5.30 ps2000SetSigGenBuiltIn

```
short ps2000_set_sig_gen_built_in (
    short          handle,
    long           offsetVoltage,
    unsigned long  pkToPk,
    PS2000_WAVE_TYPE waveType,
    float          startFrequency,
    float          stopFrequency,
    float          increment,
    float          dwellTime,
    PS2000_SWEEP_TYPE sweepType,
    unsigned long  sweeps
)
```

This function sets up the signal generator to produce a signal from a list of built-in waveforms. If different start and stop frequencies are specified, the oscilloscope will sweep either up, down or up and down.

Applicability	PicoScope 2203, 2204 and 2205 only
Arguments	<p><code>handle</code>: the handle of the required oscilloscope</p> <p><code>offsetVoltage</code>: the voltage offset, in microvolts, to be applied to the waveform</p> <p><code>pkToPk</code>: the peak-to-peak voltage, in microvolts, of the waveform signal</p> <p><code>waveType</code>: the type of waveform to be generated by the oscilloscope. See the table below.</p> <p><code>startFrequency</code>: the frequency at which the signal generator should begin. For allowable values see <code>ps2000.h</code>.</p> <p><code>stopFrequency</code>: the frequency at which the sweep should reverse direction or return to the start frequency</p> <p><code>increment</code>: the amount by which the frequency rises or falls every <code>dwellTime</code> seconds in sweep mode</p> <p><code>dwellTime</code>: the time in seconds between frequency changes in sweep mode</p> <p><code>sweepType</code>: specifies whether the frequency should sweep from <code>startFrequency</code> to <code>stopFrequency</code>, or in the opposite direction, or repeatedly reverse direction. Use one of these values of the enumerated type <code>enPS2000SweepType</code>:</p> <pre>PS2000_UP PS2000_DOWN PS2000_UPDOWN PS2000_DOWNUP</pre> <p><code>sweeps</code>: the number of times to sweep the frequency</p>
Returns	0: if successful. Error code: if failed.

waveType values

PS2000_SINE	sine wave
PS2000_SQUARE	square wave
PS2000_TRIANGLE	triangle wave
PS2000_RAMP_UP	rising sawtooth
PS2000_RAMP_DOWN	falling sawtooth
PS2000_DC_VOLTAGE	DC voltage

```

3.5.31 ps2000_set_trigger
    short ps2000_set_trigger (
        short handle,
        short source,
        short threshold,
        short direction,
        short delay,
        short auto_trigger_ms
    )
    
```

This function is used to enable or disable basic triggering and its parameters.

For oscilloscopes that support advanced triggering, see [ps2000SetAdvTriggerChannelConditions\(\)](#)^[35] and related functions.

Applicability	Triggering is available in block mode ^[57] and fast streaming mode ^[10] .
Arguments	<p><i>handle</i>, the handle of the required oscilloscope.</p> <p><i>source</i>, where to look for a trigger. Use PS2000_CHANNEL_A (0), PS2000_CHANNEL_B (1) or PS2000_NONE(5). The number of channels available depends on the oscilloscope.</p> <p><i>threshold</i>, the threshold for the trigger event. This is scaled in 16-bit ADC counts at the currently selected range.</p> <p><i>direction</i>, use PS2000_RISING (0) or PS2000_FALLING (1).</p> <p><i>delay</i>, the delay, as a percentage of the requested number of data points, between the trigger event and the start of the block. It should be in the range -100% to +100%. Thus, 0% means that the trigger event is at the first data value in the block, and -50% means that it is in the middle of the block. If you wish to specify the delay as a floating-point value, use ps2000_set_trigger2()^[52] instead.</p> <p><i>auto_trigger_ms</i>, the delay in milliseconds after which the oscilloscope will collect samples if no trigger event occurs. If this is set to zero the oscilloscope will wait for a trigger indefinitely.</p>
Returns	<p>0: if one of the parameters is out of range.</p> <p>1: if successful.</p>

```

3.5.32 ps2000_set_trigger2
    short ps2000_set_trigger2 (
        short handle,
        short source,
        short threshold,
        short direction,
        float delay,
        short auto_trigger_ms
    )

```

This function is used to enable or disable triggering and its parameters. It has the same behaviour as [ps2000_set_trigger\(\)](#)^[51], except that the `delay` parameter is a floating-point value.

For oscilloscopes that support advanced triggering, see [ps2000SetAdvTriggerChannelConditions\(\)](#)^[35] and related functions.

Applicability	Triggering is available in block mode ^[57] and fast streaming mode ^[10] only.
Arguments	<p><code>handle</code>, the handle of the required oscilloscope.</p> <p><code>source</code>, specifies where to look for a trigger. Use <code>PS2000_CHANNEL_A (0)</code>, <code>PS2000_CHANNEL_B (1)</code> or <code>PS2000_NONE (5)</code>.</p> <p><code>threshold</code>, the threshold for the trigger event. This is scaled in 16-bit ADC counts at the currently selected range.</p> <p><code>direction</code>, use <code>PS2000_RISING (0)</code> or <code>PS2000_FALLING (1)</code>.</p> <p><code>delay</code>, specifies the delay, as a percentage of the requested number of data points, between the trigger event and the start of the block. It should be in the range -100% to +100%. Thus, 0% means that the trigger event is at the first data value in the block, and -50% means that it is in the middle of the block. If you wish to specify the delay as an integer, use ps2000_set_trigger()^[51] instead.</p> <p><code>auto_trigger_ms</code>, the delay in milliseconds after which the oscilloscope will collect samples if no trigger event occurs. If this is set to zero the oscilloscope will wait for a trigger indefinitely.</p>
Returns	0: if one of the parameters is out of range. 1: if successful.

3.5.33 `ps2000_stop`

```
short ps2000_stop (  
    short handle  
)
```

Call this function to stop the oscilloscope sampling data. If this function is called before a trigger event occurs, the oscilloscope may not contain valid data.

Applicability	All modes.
Arguments	<code>handle</code> , the handle of the required oscilloscope.
Returns	0: if an invalid handle is passed. 1: if successful.

3.5.34 `my_get_overview_buffers`

```
void my_get_overview_buffers (
    short          **overviewBuffers,
    short          overflow,
    unsigned long  triggeredAt,
    short          triggered,
    short          auto_stop,
    unsigned long  nValues
)
```

This is the callback function in your application that receives data from the driver in [fast streaming](#) mode. You pass a pointer to this function to [ps2000_get_streaming_last_values\(\)](#), which then calls it back when the data is ready. Your callback function should do nothing more than copy the data to another buffer within your application. To maintain the best application performance, the function should return as quickly as possible without attempting to process or display the data.

The function name `my_get_overview_buffers()` is arbitrary. When you write this function, you can give it any name you wish. The PicoScope driver does not need to know your function's name, as it refers to it only by the pointer that you pass to [ps2000_get_streaming_last_values\(\)](#).

For an example of a suitable callback function, see the [C sample code](#) included in your PicoScope installation.

Applicability	<p>Fast streaming^[10] mode only.</p> <p>PicoScope 2203, 2204 and 2205 only.</p> <p>Not compatible with ETS^[8] triggering - has no effect in ETS mode.</p>
Arguments	<p><code>overviewBuffers</code>, a pointer to a location where ps2000_get_streaming_last_values()^[16] will store a pointer to its overview buffers^[57] that contain the sampled data. The driver creates the overview buffers when you call ps2000_run_streaming_ns()^[34] to start fast streaming.</p> <p><code>overflow</code>, a bit field that indicates whether there has been a voltage overflow and, if so, on which channel. The bit assignments are as follows:</p> <ul style="list-style-type: none"> Bit 0 - Ch A overflow Bit 1 - Ch B overflow <p><code>triggeredAt</code>, an index into the overview buffers, indicating the sample at the trigger event. Valid only when <code>triggered</code> is <code>TRUE</code>.</p> <p><code>triggered</code>, a Boolean indicating whether a trigger event has occurred and <code>triggeredAt</code> is valid. Any non-zero value signifies <code>TRUE</code>.</p> <p><code>auto_stop</code>, a Boolean indicating whether streaming data capture has automatically stopped. Any non-zero value signifies <code>TRUE</code>.</p> <p><code>nValues</code>, the number of values in each overview buffer.</p>
Returns	nothing

3.6 Driver error codes

Code	Name	Description
0	PS2000_OK	The oscilloscope is functioning correctly.
1	PS2000_MAX_UNITS_OPENED	Attempts have been made to open more than PS2000_MAX_UNITS oscilloscopes.
2	PS2000_MEM_FAIL	Not enough memory could be allocated on the host machine.
3	PS2000_NOT_FOUND	An oscilloscope could not be found.
4	PS2000_FW_FAIL	Unable to download firmware.
5	PS2000_NOT_RESPONDING	The oscilloscope is not responding to commands from the PC.
6	PS2000_CONFIG_FAIL	The configuration information in the oscilloscope has become corrupt or is missing.
7	PS2000_OS_NOT_SUPPORTED	The operating system is not Windows XP SP2 or Vista.

4 Glossary

Aggregation. In [fast streaming mode](#)^[10], the PicoScope 2000 driver can use a method called aggregation to reduce the amount of data your application needs to process. This means that for every block of consecutive samples, it stores only the minimum and maximum values. You can set the number of samples in each block, called the aggregation parameter, when you call [ps2000_run_streaming_ns\(\)](#)^[34] for real-time capture, and when you call [ps2000_get_streaming_values\(\)](#)^[17] to obtain post-processed data.

Analog bandwidth. The input frequency at which the signal amplitude has fallen by 3 dB, or by half the power, from its nominal value.

Block mode. A sampling mode in which the computer prompts the oscilloscope to collect a block of data into its internal memory before stopping the oscilloscope and transferring the whole block into computer memory. This is the best mode to use when the input signal being sampled contains high frequencies. To avoid aliasing effects, the sampling rate must be greater than twice the maximum frequency in the input signal.

Buffer size. The size of the oscilloscope's buffer memory. The oscilloscope uses this to store data temporarily so that it can sample data independently of the speed at which it can transfer data to the computer.

Coupling mode. This mode selects either AC or DC coupling in the oscilloscope's input path. Use AC mode for small signals that may be superimposed on a DC level. Use DC mode for measuring absolute voltage levels. Set the coupling mode using [ps2000_set_channel\(\)](#)^[41].

Driver. A piece of software that controls a hardware device. The driver for the PicoScope 2000 Series PC Oscilloscopes is supplied in the form of a 32-bit Windows [DLL](#)^[4], which contains [functions](#)^[13] that you can call from your application.

ETS. Equivalent time sampling. Some PicoScope 2000 Series oscilloscopes can collect data over a number of cycles of a repetitive waveform to give a higher effective sampling rate than is possible for a single cycle. Equivalent time sampling allows the oscilloscope to use faster timebases than those available in real-time mode.

Maximum sampling rate. A figure indicating the maximum number of samples the oscilloscope is capable of acquiring per second. Maximum sample rates are usually given in MS/s (megasamples per second) or GS/s (gigasamples per second). The higher the sampling speed of the oscilloscope, the more accurate the representation of the high-frequency details in a fast signal.

Oversampling. A method of increasing the effective resolution of a measurement by sampling faster than the required sampling rate, then averaging the extra samples. An oversampling factor of four increases the effective resolution by one bit, but this increased resolution comes at the expense of reducing the maximum sampling rate by the same factor.

Overview buffer. A buffer in the PC's memory in which the PicoScope 2000 Series driver temporarily stores data on its way from the oscilloscope to the application's buffer.

PC Oscilloscope. A virtual instrument consisting of a PicoScope PC Oscilloscope and a software application.

PicoScope 2000 Series. A range of low-cost PC Oscilloscopes that includes the PicoScope 2202, 2203, 2204 and 2205 two-channel oscilloscopes and the PicoScope 2104 and 2105 handheld oscilloscopes.

PicoScope software. This is an application that accompanies all our PC Oscilloscopes. Although you do not need it if you are writing your own application, you should install it anyway, because it includes the drivers that you will need to control the oscilloscope.

Real-time continuous mode. A sampling mode in which the software repeatedly requests single samples from the oscilloscope. This mode is suitable for low sampling rates when you require the latest sample to be displayed as soon as it is captured.

Streaming mode. A sampling mode in which the oscilloscope samples data and returns it to the computer in an unbroken stream. This mode of operation is suitable when the input signal being sampled contains only low frequencies.

Timebase. A number that is supplied to the driver to specify a sampling rate for the oscilloscope. Each oscilloscope model has a different range of possible sampling frequencies, as specified in the User's Guide for that model.

USB 1.1. Universal Serial Bus (Full Speed). This is a standard port that enables you to connect external devices to PCs. A typical USB 1.1 port supports a data transfer rate of 12 megabits per second, and is much faster than an RS-232 or COM port.

USB 2.0. Universal Serial Bus (High Speed). This is a standard port that enables you to connect external devices to PCs. A typical USB 2.0 port supports a data transfer rate of 480 megabits per second, and is backwards-compatible with USB 1.1.

Vertical resolution. A value, in bits, that indicates the number of input voltage levels that the oscilloscope can distinguish. Calculation techniques can improve the effective resolution.

Voltage range. The range of input voltages that the oscilloscope will measure in a given mode.

Windows Device Manager. Windows Device Manager is a component of Microsoft Windows that displays the current hardware configuration of your computer. On Windows XP or Vista, right-click My Computer, choose Properties, click the Hardware tab and then the Device Manager button.

Index

A

AC/DC coupling 4, 41
 Advanced triggering 37
 Advanged triggering 35, 38, 40, 45
 Aggregation 10, 17, 34
 Agilent VEE example code 12
 Aliasing 5

B

Block mode 5, 7, 8, 32

C

C example code 11
 Callback 54
 Channel 4, 41, 51, 52
 Closing a unit 14
 Compatible streaming mode 9
 Contact details 2

D

Data acquisition 10
 Data logger 1
 Delphi example code 12
 Driver 4
 error codes 56

E

Error codes 56
 ETS 8, 42
 Example code
 Agilent VEE 12
 C 11
 Dephi 12
 Excel 12
 LabView 12
 Visual Basic 12
 Excel macros 12
 External trigger 5, 51, 52

F

Fast streaming mode 10
 Functions 13
 my_get_overview_buffers 54
 ps2000_close_unit 14

ps2000_flash_led 15
 ps2000_get_streaming_last_values 16
 ps2000_get_streaming_values 17

 ps2000_get_streaming_values_no_aggregation 19
 ps2000_get_timebase 21
 ps2000_get_times_and_values 22
 ps2000_get_unit_info 24
 ps2000_get_values 25
 ps2000_last_button_press 26
 ps2000_open_unit 27
 ps2000_open_unit_async 28
 ps2000_open_unit_progress 29
 ps2000_overview_buffer_status 30
 ps2000_ready 31
 ps2000_run_block 32
 ps2000_run_streaming 33
 ps2000_run_streaming_ns 34
 ps2000_set_channel 41
 ps2000_set_ets 42
 ps2000_set_led 44
 ps2000_set_light 43
 ps2000_set_trigger 51
 ps2000_set_trigger2 52
 ps2000_stop 53
 ps2000SetAdvTriggerChannelConditions 35
 ps2000SetAdvTriggerChannelDirections 37
 ps2000SetAdvTriggerChannelProperties 38
 ps2000SetAdvTriggerDelay 40
 ps2000SetPulseWidthQualifier 45
 ps2000SetSigGenArbitrary 47
 ps2000SetSigGenBuiltIn 49

G

Gain 4
 Ground clip 3

H

Headlight 43
 High-precision scopes 10

I

Illuminated button 3
 Input connector 3
 Installation 3

L

LabView driver 12
 LED 15, 44

Licence conditions 1
Light 3, 43

M

Macros in Excel 12
Memory in scope 7
Multi-unit operation 6

N

Normal mode 9

O

One-shot signal 8
Opening a unit 27, 28, 29
Oversampling 5
Overview buffer 30

P

PC Oscilloscope 1
PicoLog software 1
picopp.inf 4
picopp.sys 4
PicoScope 2000 Series 1, 6, 56
PicoScope software 1, 4, 56
Pre-trigger 5
Probe 3
PS2000_PWQ_CONDITIONS structure 46
PS2000_THRESHOLD_DIRECTION constants 37
PS2000_TRIGGER_CHANNEL_PROPERTIES structure 39
PS2000_TRIGGER_CONDITIONS structure 36

R

Resolution, vertical 5

S

Sampling modes 6
Sampling rate 8
Signal generator 5, 7
 arbitrary waveforms 47
 built-in waveforms 49
Spectrum analyser 1
Stopping sampling 53
Streaming mode
 compatible 9
 fast 10
 normal 9
 windowed 9

Sweep 5
System requirements, minimum 3

T

Threshold voltage 5
Time interval 5, 8
Timebase 21, 32
Trademarks 2
Triggering 5, 8, 51, 52

U

USB 1
 hub 6
USB cable 3

V

Vertical resolution 5
Visual Basic example code 12

W

Warranty 2
Windowed mode 9

Pico Technology

James House
Colmworth Business Park
Eaton Socon
ST. NEOTS
Cambridgeshire
PE19 8YP
United Kingdom
Tel: +44 (0) 1480 396 395
Fax: +44 (0) 1480 396 296
Web: www.picotech.com

ps2000pg.en-1

31.1.08

Copyright 2006-8 Pico Technology Limited. All rights reserved.